



Solid blocking or herring-bone strutting is NOT required on the SIMPLE FRAMING SYSTEM®.

For installation stability, see Temporary Construction Bracing details on page 27.

